TECHNICAL SPECIFICATIONS

VIDEO	
Format	DisplayPort
Input Interface	(8) DisplayPort
Output Interface	(1) DisplayPort
Resolution	Up to 4K (3840x2160 @30Hz)
DDC	5 volts p-p (TTL)
Input Equalization	Automatic
Input Cable Length	Up to 20 ft.
Output Cable Length	Up to 20 ft.
USB	
Signal Type	USB 2.0, 1.1, and 1.0 w/ internal hub
Input Interface	(8) USB Type B
Output Interface	(2) USB 1.1 Type A for KVM Devices (2) USB 2.0 Type A Transparent
AUDIO	
Input	(8) 3.5 mm Stereo Audio
Output	(1) 3.5 mm Stereo Audio
POWER	
Power Requirements	12V DC, 2A power adapter with center-pin positive polarity
ENVIRONMENT	
Operating Temp	32° to 104° F (0° to 40° C)
Storage Temp	-4° to 140° F (-20° to 60° C)
Humidity	0-80% RH, non-condensing
CONTROL	
Front Panel	Push Buttons with LED indicators
RS-232	Via Serial @ 115200 bps
Hot Keys	Via Keyboard
OTHER	
Emulation	Keyboard, Mouse and Video

WHAT'S IN THE BOX

PART NO.	QTY	DESCRIPTION
SM-EDPN-8S-S	1	8-Port DP KVM Switch with Audio and USB 2.0 Support.
PS12VD3A	1	12V DC, 2A power adapter with center-pin positive polarity.
	1	Quick Start Guide

NOTICE

DESIGNED AND MADE IN THE USA

Toll Free: (800) AVI-2123
Phone: (702) 800-0005

2455 W. Cheyenne Ave, Suite 112
North Las Vegas, NV 89032

smartavi.com

Smart-AVI
SMART AUDIO VIDEO INNOVATION

SM-EDPN-8S

Advanced KVM Switch

8-PORT DP KVM SWITCH WITH USB 2.0 SHARING

Quick Start Guide

A full Manual can be downloaded from
www.smartavi.com/SM-EDPN-8S/

EDID LEARN

The KVM is designed to learn a connected monitor's EDID upon power up. In the event of connecting a new monitor to the KVM, a power re-cycle is required.

SYSTEM CONTROL

There are three ways to control the SM-EDPN: Keyboard HotKeys, RS-232 Serial Commands, and Front Panel Buttons.
The settings for the serial connection are as follows: Baud rate: <u>115200</u>; Data Bits: <u>8</u>; Parity: <u>None</u>; Stop Bits: <u>1</u>; Flow Control: <u>None</u>.

The following commands can be used:

Command	HotKey	RS-232
Switch KVM	`[CT][CT][#]<CR>`	`//m[#]<CR>`
Audio Only	`[CT][CT]a[#]<CR>`	`//a[#]<CR>`
KM Only	`[CT][CT]c[#]<CR>`	`//c[#]<CR>`
USB Only	`[CT][CT]u[#]<CR>`	`//u[#]<CR>`
Learn EDID	`[CT][CT]e <CR>`	`//e <CR>`
SW Reset	`[CT][CT]r`	`//r <CR>`
Status Query	`N/A`	`//?? <CR>`
Current HK Trigger	`[Alt][Alt][Alt] x 0 <CR>`	`//hk <CR>`
Update HK Trigger	`[HK][HK] x [1|2|3] <CR>`	`N/A`

Chart Key

`[CT]` = Ctrl
`<CR>` = Carriage Return (Enter Key)
`[HK]` = Current Hot Key Trigger
1 = Ctrl (Default) | 2 = Shift | 3 = Scroll Lock

HARDWARE INSTALLATION

1. Ensure that power is turned off or disconnected from the unit and the computers.
2. Use DP cables to connect the DP output ports from each computer to the corresponding DP ports of the unit.
3. Use a USB cable (Type-A to Type-B) to connect a USB port on each computer to the respective USB ports of the unit.
4. Optionally connect a stereo audio cable (3.5mm to 3.5mm) to connect the audio output of the computers to the AUDIO IN ports of the unit.
5. Connect monitors to the DP console ports of the unit using DP cables.
6. Connect a USB keyboard and mouse in the two USB console ports.
7. Optionally connect stereo speakers to the AUDIO OUT port of the unit.
8. Finally, power on the KVM by connecting a 12VDC power supply to the power connector, and then turn on all the computers.

Note: You can connect up to 8 computers to the 8 port KVM.

- DP IN
- DP OUT
- USB IN
- USB K/M OUT
- USB 2.0 OUT
- AUDIO IN
- AUDIO OUT