

SignagePro Commander

Digital Signage and Video Wall Controller Start Up Guide



Control SmartAVI digital signage or video wall players over RS-232 with the 16-button SignagePro Commander



Start Up Instructions

1. Connect SignagePro Commander to the SmartAVI digital signage or video wall player via USB
2. Plug in the SignagePro Commander's 5 volt power supply
3. Install driver from the included CD (*SmartAVI's PresenterWall and SignWall product line have the driver pre-installed, so there is no need to re-install the driver.*)
4. Pressing the front panel buttons will send the following command to the digital signage or video wall player: `/Start1` - `/Stop1`, etc
(*PresenterWall and SignWall trigger commands don't require the slash: "Start1" - "Stop1", etc*)

