


N2N KVM OVER IP SOFTWARE

N2N MANAGER

Centralized desktop management
for the complete N2N system

Discover and configure N2N endpoints, manage users and permissions, and operate remote computers through live KVM and multiview from one application.



N2N-MGR V1.0 N2N Manager Ver1.0 for Windows



Device discovery

Find N2N endpoints on the local network



Access control

Create users and assign permissions



Live KVM

View and control remote computers




Multiview

Build 2x2 or custom viewing grids

Manage the entire N2N system from one console

Search the network, review endpoint status, and apply device or network changes without moving between separate tools



01

Discover endpoints

Search the local network and populate one live device table.

02

Configure devices

Update device identity, model, IP address, subnet, gateway, and related settings.

03

Set operating roles

Apply settings for N2N transmitters, receivers, and KVM endpoints.


04

Confirm changes

Device ID, name, and model updates appear immediately on the endpoint OLED.

Control access and standardize system settings

N2N Manager combines day-to-day user administration with the tools needed to maintain a consistent deployment.



USER ADMINISTRATION

Add, modify, and remove user accounts from one administrative view.

Assign the appropriate access permission for each user and manage access to sources, groups, and sites.

SYSTEM CONFIGURATION

Save application settings for consistent operation across the deployment.


Restore factory data when needed, then restart the application to apply the new configuration.

One administrative console

Manage access, maintain configuration, and support day-to-day N2N operations from the same desktop application.

From live monitoring to full keyboard and mouse control

Preview connected sources, arrange them on the main canvas, and take control of the selected remote computer.



01

Preview

See connected sources in the preview panel.

02

Arrange

Drag a source into the main viewing canvas.

03

Control

Open full-screen KVM for active keyboard and mouse control.

04

Multiview

Choose a 2x2 layout or create a custom grid.

Ordering Info

Part No N2N-MGR V1.0 N2N Manager Ver1.0 for Windows