

## TECHNICAL SPECIFICATIONS

VIDEO	
Format	DVI-I Dual Link
Host Interface	(4) DVI-I 29-pin (female)
User Console Interface	(2) DVI-I 29-pin (female)
Max Resolution	2560 x 1600 @ 60Hz; 3840x2160 @ 30Hz
DDC	5 volts p-p (TTL)
Input Equalization	Automatic
Input Cable Length	Up to 20 ft.
Output Cable Length	Up to 20 ft.
USB	
Signal Type	USB 1.1 and 1.0 Keyboard and Mouse only. USB 2.0 for CAC connection.
USB Type B Inputs	(4) Keyboard-Mouse; (4) CAC
User Console Output Interface	(2) USB Type-A for keyboard and mouse connection only. (1) USB Type-A for CAC connection.
AUDIO	
Input	(4) Connector Stereo 3.5mm Female
Output	(1) Connector Stereo 3.5mm Female
POWER	
Power Requirements	12V DC, 2A power adapter with center-pin positive polarity
ENVIRONMENT	
Operating Temp	32° to 104° F (0° to 40° C)
Storage Temp	-4° to 140° F (-20° to 60° C)
Humidity	0-80% RH, non-condensing
CERTIFICATIONS	
Security Accreditation	Common Criteria Validated To NIAP, Protection Profile PSS Ver. 3.0
OTHER	
Emulation	USB 1.1 and USB 2.0 Compatible
Control	Front Panel Buttons

## WHAT'S IN THE BOX

PART NO.	QTY	DESCRIPTION
SDMN-4S-P	1	4-port, Secure DVI-I KVM Switch
PS12VDC2A	1	12V DC, 2A power adapter with center-pin positive polarity.
	1	Quick Start Guide

## NOTICE

The information contained in this document is subject to change without notice. iPGARD makes no warranty of any kind with regard to this material, including but not limited to, implied warranties of merchantability and fitness for particular purpose. iPGARD will not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material. No part of this document may be photocopied, reproduced, or translated into another language without prior written consent from iPGARD, Inc.

20170518



DESIGNED  
AND MADE  
IN THE USA

**Toll Free: (888) 994-7427**

**Phone: (702) 990-0523**

**Fax: (702) 441-5590**

**3291 N. Jones Blvd.,  
Las Vegas, NV 89108**

**iPGARD.COM**

# iPGARD™

## SDMN-4S-P

### Secure KVM Switch



**Advanced 4-Port Secure  
Single-head DVI-I KVM Switch  
with Audio, CAC Support and  
Preview Screen**

### Quick Start Guide

A full Manual can be downloaded from  
[www.ipgard.com/documentation/](http://www.ipgard.com/documentation/)

## EDID LEARN

The KVM is designed to learn a connected monitor's EDID upon power up. In the event of connecting a new monitor to the KVM, a power recycle is required.

The KVM will indicate the unit's EDID learn process is active by flashing the front panel's LEDs. In sequential order. Starting with the LED above button "1" on the front panel, each LED will flash green for approximately 10 seconds upon beginning the EDID learn. Once all the LEDs stop flashing, the LEDs will cycle and the EDID learn will be complete.

A monitor must be connected to the video output port located in the console space at the back of the KVM during the EDID learn process.

If the read EDID from the connected monitor is identical to the current stored EDID in the KVM then the EDID learn function will be skipped.

A full Manual can be downloaded from [www.ipgard.com/documentation/](http://www.ipgard.com/documentation/)




## HARDWARE INSTALLATION

1. Ensure that power is turned off or disconnected from the unit and the computers.
2. Use a DVI cable to connect the DVI output port from each computer to the corresponding DVI-I IN ports of the unit.
3. Use a USB cable (Type-A to Type-B) to connect a USB port on each computer to the respective USB ports of the unit.
4. Optionally connect a stereo audio cable (3.5mm to 3.5mm) to connect the audio output of the computers to the AUDIO IN ports of the unit.
5. Connect a monitor to the DVI-I OUT console port of the unit using a DVI cable.
6. Connect a USB keyboard and mouse in the two USB console ports.
7. Optionally connect stereo speakers to the AUDIO OUT port of the unit.
8. Optionally connect CAC (COMMON ACCESS CARD, SMART CARD READER) to the CAC port in the user console interface.
9. Finally, power on the KVM by connecting a 12VDC power supply to the power connector, and then turn on all the computers.

**Note:** The computer connected to port 1 will always be selected by default after power up.

**Note:** You can connect up to 4 computers to the 4 port KVM.



A full Manual can be downloaded from [www.ipgard.com/documentation/](http://www.ipgard.com/documentation/)